



CP40 Firmware Upgrade/Replacement

To upgrade or replace a CP40 firmware chip, please follow the steps below.

STEP 1: Power off the CP40 controller in question.

STEP 2: Remove the existing firmware chip and replace it with the new firmware chip. The notch on the firmware chip must be facing up.

NOTE: Improper installation of the chip will burn it out and void the warranty.


STEP 3: Power on the CP40 controller.

STEP 4: Clear the panel memory:

- On the **Options DIP Switch (S2)**, push **switch 5** to the right (**ON**)
- Press and release the **Reset** button
- Wait 15 seconds until **LED 3** starts flashing quickly
- Push **switch 5** back to the left (**OFF**)
- Press and release the **Reset** button
- Panel is now cleared to virgin state and ready for operation



DIP Switch 5



Reset Button

STEP 5: In the Hurricane or Maestro software, download the controller information via **Commands > Controller Download**